

## PROKERLAM SQUARE

ANODIZED SILVER, POLISHED CHROME AND GOLD ALUMINIUM

PKLQ... 045 H 4,5 mm 5,5 mm 6 mm



 Choose "PROKERLAM SQUARE" according to the desired finish.
 Cut "PROKERLAM SQUARE" to the desired length and apply the adhesive on the support where the profile will be laid. 3. Press the anchoring flange of "PROKERLAM SQUARE" into the adhesive. 4. Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile.
 Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile.



#### ANODIZED SILVER ALUMINIUM thermo packed bar length 2,7 Im - pack. 40 Pcs - 108 Im

even with low thickness coverings.

 Article
 H mm

 PKLQAA 045
 4,5

## COLOURS

		1000
AA - Anodized silver alum.	BC - Polished chrome alum.	BO - Polished gold alum.

White

POLISHED GOLD ALUMINIUM thermo packed bar length 2,7 lm - pack. 40 Pcs - 108 lm

0, 1		 
Article	H mm	
PKLQBO 045	4,5	

POLISHED CHROME ALUMINIUM thermo packed bar length 2.7 Im - pack. 40 Pcs - 108 Im

· · · · · · · · · · · · · · · · · · ·		
Article	H mm	
PKLQBC 045	4,5	

# PROKERLAM JOLLY

ANODIZED AND POLISHED ALUMINIUM SILVER, CHROME AND GOLD



PROKERLAM SQUARE is a square corner bead profile in anodized and polished aluminium suitable to protect the

external corners of coverings with low thickness. It can be used like connection profile between step tread and riser of stairs coated with ceramic and mosaic with low thickness. Its particular section and the availability in three

different finishes make PROKERLAM SQUARE a much sought-after profile that allows a workmanlike application

H 4,5 mm

**EXAMPLE FOR LAYING** 

PKLJ... 045



 Choose "PROKERLAM Jolly" according to the desired finish.
 Cut "PROKERLAM Jolly" to the desired length and apply the adhesive on the support where the profile will be laid. 3. Press the anchoring flange of "PROKERLAM Jolly" into the adhesive. 4. Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile.
 Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile.



ANODIZED SILVER ALUMINIUM thermo packed bar length 2,7 Im - pack. 40 Pcs - 108 Im

	Article	H mm		
	PKLJAA 045	4,5		

### COLOURS





POLISHED CHROME ALUMINIUM thermo packed bar length 2,7 Im - pack. 40 Pcs - 108 Im

Article	H mm	
PKLJBC 045	4,5	

POLISHED GOLD ALUMINIUM thermo packed

Dai lengui 2,7 mi - pack. 40 FCS - 100 mi			
	Article	Hmm	
	PKLJBO 045	4,5	

156