
PROFLEX ACN

STAINLESS STEEL AISI 304/1.4301-V2A

PROFLEX ACN is a movement joint suitable for vehicular traffic composed by two interlocked sliding stainless steel profiles. The two stainless steel profiles have punched flanges which guarantee a perfect fixing to the support and a correct movement. **PROFLEX ACN** stainless steel is suitable for all areas with heavy chemical and mechanical stress. Lay the joints according to UNI 11493-1.

PROFLEX ALN is a new, natural aluminium expansion joint consisting of two interlocked sliding profiles designed for glued floors. **PROFLEX ALN** provides elastic expansion joints for various kinds of flooring, such as ceramic, marble, granite, Kerilite or any other flooring material laid with glue/adhesive and having a thickness of 8 to 20 mm. The joint is specially designed to protect the edges of the tiles, and its exceptional strength makes it capable of supporting frequent traffic, both pedestrian and vehicular (forklifts, pallet trucks, automobiles). The joint must be installed at the same level of the floor or 0.5-1 mm lower (never above). Lay the joints are used by the protect of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength user of the same level of the floor or 0.5-1 mm lower (never above). Lay the joint strength above (never above) ab

according with the standards in force. HIGH RESISTANCE TO LOADS AND TO FREQUENT TRAFFIC OF PALLET TRUCKS AND FORKLIFTS.





SUITABLE FOR USE IN CONTACT WITH FOODSTUFFS

EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS

POLISHED STAINLESS STEEL AISI 304/1.4301-V2A bar length **2.5 lm** - pack. **10 Pcs - 25 lm**

| Article | Hmm | | | | |
|------------|------|--|--|--|--|
| PFXACN 08 | 8 | | | | |
| PFXACN 10 | 10 | | | | |
| PFXACN 11 | 11 | | | | |
| PFXACN 125 | 12,5 | | | | |
| PFXACN 15 | 15 | | | | |
| PFXACN 20 | 20 | | | | |
| PFXACN 25 | 25 | | | | |
| PFXACN 30 | 30 | | | | |
| | | | | | |



ACM - Polished stainless st. AISI 316LL


*Minimum quantity 200 pcs. Price to be agreed. Production delay 4/5 weeks.

1. Choose the PROFLEX ACN with the same height as the thickness of the floor (tile). 2. Using a notched spreader apply the adhesive in the point where the joint will be laid. 3. Lay the PROFLEX ACN with the punched flanges in the adhesive (we recommend the expansion joint being laid in line with the joint in the screed/floor rough). A Lay the tiles, aligning them with and adjoining the upper edge of the profile (the joint must always be 0.5-1mm lower than the tile, never above). Always place the uncut side of the tile against the profile. **5.** Use sealant to fill any spaces between the tile and the PROFLEX ACN joint.

AVAILABLE H 11mm - PFXACN 11, H 25mm - PFXACN 25, H 30mm - PFXACN 30

PROFLEX ALN

NATURAL ALUMINIUM





NATURAL ALUMINIUM bar length 2,5 lm - pack. 20 Pcs - 50 lm

| Article | Hmm | |
|------------------------|------|--|
| PFXALN 08 | 8 | |
| PFXALN 10 | 10 | |
| PFXALN 125 | 12,5 | |
| PFXALN 15 | 15 | |
| PFXALN 20 | 20 | |
| COLOURS | | |
| | | |
| AN - Natural aluminium | | |



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



1. Choose the PROFLEX ALN with the same height as the thickness of the floor (tile). 2. Using a notched spreader apply the adhesive in the point where the joint will be laid. 3. Lay the PROFLEX ALN with the punched flanges in the adhesive (we recommend the expansion joint being laid in line with the joint in the screed/floor rough). 4. Lay the tiles, aligning them with and adjoining the upper edge of the profile (the joint must always be 0.5-1mm lower than the tile, never above). Always place the uncut side of the tile against the profile. **5.** Use sealant to fill any spaces between the tile and the PROFLEX ALN joint.