

PROMULTIFIX SYSTEM®

INSTRUCTIONS FOR LAYING



PROGRESS PROFILES® has filed an innovative patent PROMULTIFIX SYSTEM® in respect of a wide range of aluminum profiles covered with very strong films in wooden finishes, plus anodized finishes.

The PROMULTIFIX SYSTEM® system is a multipurpose profile for finishing laminate, melamine-coated, parquet and wood floating floors.

FIXING: it can be fixed with adhesive, nylon anchors, glue, flatten down base and screws.

STANDARD Wooden FINISHES: Light oak (strip), Light cherry (strip), Red walnut (merbau-apple-walnut), Light zerbano, Oak powder, White oak, Grey oak, Victoria oak, Pink oak, Havana oak, Edinburgh oak, Carvi oak, Ice oak, Grace oak, Honey oak, Black decapè, Cork oak, Sand oak, Tripoli, Bangkok, Liotard, New white.

STANDARD ALUMINUM FINISHES: anodized Silver, Gold and Bronze.

ANODIZED COLOURS




* ANODIZED COLOURS ON DEMAND




WOODEN COLOURS

(For a precise assessment of colours request the wooden finishes sample range)



* WOODEN COLOURS ON DEMAND



On request it is possible to realize other finishes of the color range: minimum order 200 pcs. Production delay 4/5 weeks. Price to be agreed. For sample finishes, contact the sales office for minimum quantities, timing and costs.

PROMULTIFIX SYSTEM

PROMULTIFIX SYSTEM is composed of an aluminium profile with adhesive, with a lengthwise groove in form of dovetail, where nylon anchors can be inserted, or a punched aluminium flatten down base for an easy and invisible fixing.

NYLON SCREW ANCHORS



PERIMETRIC SUPPORTS



FLATTEN DOWN BASE



LEGNO / LVT


It is a system composed of a special TOP with adhesive, with a visible surface of 44.7 mm, anodized aluminium or covered with wooden film. The aluminium TOP can be fixed to the floor in different ways: with adhesive, with nylon anchors, support with removable spacers, flatten down base.

PROMULTIFIX SYSTEM


ALUMINIUM PROFILES
FIXING KIT




PMPFX... 42090AS / 42A



PMPFX... 42090AS / 42A



PMPFX... 42090AS / 42A + PMFIXBSAN 23



TOP IN ANOD. ALUMINIUM with adhesive (6 finishes of which 3 on demand) n.3 KIT (15 screws, 12 perimeter pins, 6 joints) thermo packed - bar length 2,7 lm - pack. 20 Pcs - 54 lm

Article	L mm
PMPFX... 42A	44,7

TOP IN ANOD. ALUMINIUM with adhesive (6 finishes of which 3 on demand) + n.1 KIT (5 screws, 4 perimeter pins, 2 joints) thermo packed - bar length 0,90 lm - 15 Pcs

Article	L mm
PMPFX... 42090AS	44,7

TOP IN ALUM. COVERED with adhesive (80 wooden finishes of which 59 on demand) + n.3 KIT (15 screws, 12 perimeter pins, 6 joints) thermo packed - bar length 2,7 lm - pack. 20 Pcs - 54 lm

Article	L mm
PMPFX... 42A	44,7

TOP IN ALUM. COVERED with adhesive (80 wooden finishes of which 59 on demand) + n.1 KIT (5 screws, 4 perimeter pins, 2 joints) thermo packed - bar length 0,90 lm - 15 Pcs



Article	L mm
PMPFX... 42090AS	44,7

Available in the colours: AO - AA - AB (AT, CH and SB on demand with a minimum quantity order of 200 pcs) and in the wooden finishes: 05W - 07W - 09W - 18W - 21W - 29W - 30W - 31W - 32W - 34W - 35W - 37W - 41W - 42W - 44W - 46W - 48W - 49W - 65W - 73W - 75W - 93W. The code of the selected colour must be added to the article code. E.g.: PMPFX... 42A(chosen finish anod. gold) PMPFXAO 42A.

EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS

1. Choose the profile of the required finish, if necessary cut the TOP in the required length.
 2. Clean, remove the grease and dry the substrate: the temperature should be at least of 15° C.
 3. Remove the paper protection from the adhesive and lay the TOP with a vertical pressure without moving the profile.
 4. Remove the paper protection from the adhesive.
 5. Insert the screw anchors in the profile dovetail groove.
 6. Beat with a rubber/pvc hammer to insert the screw anchors into the holes.
 7. Make a uniform pressure on the profile with the hands or a rubber hammer.
- Fixing with biadhesive tape:**
1. Remove the paper protection from the adhesive and lay the TOP with a vertical pressure without moving the profile.
 2. Make a uniform pressure on the profile with the hands or a rubber hammer.
- Fixing with screw anchors:**
1. Remove the paper protection from the adhesive and lay the TOP with a vertical pressure without moving the profile.
 2. Make a uniform pressure on the profile with the hands or a rubber hammer.
- Fixing of the aluminium flatten down base:**
1. Cut the flatten down base to the requested length.
 2. Remove the paper protection from the adhesive.
 3. Insert the base into the profile groove dovetail, then fix or glue the base to the floor.
 4. Make a uniform pressure on the profile with the hands or a rubber hammer.
- Perimetric laying:**
1. Remove the paper protection from the adhesive.
 2. Cut the perimetric pins according to the thickness of the floor.
 3. Insert the perimetric pins into the profile groove dovetail using 4 supports per linear meter.
 4. Fix the profil making a uniform pressure on the profile with the hands, but do not move the profile.

One fixing kit is composed of: 5 screws, 4 perimetric pins, 2 joints




SCREWS AND SCREW ANCHORS, TAP-DOWN BASE

NICKEL - PLATED FLATHEAD SCREWS + SCREW ANCHORS

pack. 1.000 Pcs

Article	Ø mm	L mm
VINIPT 325	3	25



PROFIXER TAP-DOWN BASE - ALUM. PUNCHED/PERFORED

bar length 2,7 lm - pack. 20 Pcs - 54 lm

Article	H mm
PMFIXBSAN 23	23

